

# SARS-CoV-2 S1RBD-ACE2 Binding assay Kit (CAT NO: 41A249R)

For detection of neutralizing antibodies in plasma/serum, vaccine development, screening drugs and antibodies against COVID-19

This package insert must be read in its entirely before using this product



# BACKGROUND

The ongoing global pandemic of coronavirus disease 2019 (COVID-19) is caused by severe acute respiratory syndrome coronavirus 2 (SARS-COV-2). SARS-CoV-2 is an enveloped virus with a positive-sense RNA genome and a nucleocapsid of helical symmetry. The SARS-CoV-2 entry into host cells is mediated by the transmembrane spike (S) glycoprotein, which contains a receptor binding domain (RBD). S1RBD is responsible for binding with angiotensin converting enzyme-2 (ACE2), leading to endocytosis into the host cells and viral replication. S1RBD is the main target of neutralizing antibodies upon infection and the focus of the therapeutic drug and vaccine design. Molecules that inhibit formation of the S1RBD-ACE2 complex *in vitro* could be potential treatment for COVID-19 infection.


#### **INTENDED USE**

The Torontobioscience SARS-COV2 S1RBD-ACE2 Binding Assay is designed to measure the interaction between the receptor binding domain of the viral spike glycoprotein (S1RBD) with the cell surface receptor ACE2. The assay can detect the neutralizing antibodies in human plasma or serum which inhibit the S1RBD-ACE2 interaction, and can also be used for screening the inhibitors and potential drugs and vaccine development.

# This product is intended for research use only.

#### **ASSAY PRINCIPLE**

The SARS-COV2 S1RBD-ACE2 Binding Assay is competitive ELISA assay, which can mimic the virus neutralization process. 96-well plates are coated with SARS-CoV-2 S1RBD protein that captures neutralization antibodies or compounds which bind to SARS-CoV-2 S1RBD protein in the sample. After washing away unbound materials, captured neutralization antibodies or compounds can block the binding between horseradish peroxidase (HRP) conjugated recombinant human ACE2. After washing step, the chromogenic substrate 3,3',5,5'-tetramethylbenzidine (TMB) is added. Color reaction is stopped by 2M H<sub>2</sub>SO<sub>4</sub>. The inhibitory efficiency of neutralization antibodies or compounds or compounds against SARS-CoV-2 S1RBD captured inside the wells is inversely proportional to the color density generated in the coupled oxidation-reduction reaction.



#### **REAGENTS SUPPLIED**

Each kit is sufficient for 96 tests and contains the following components:

- 1. One aluminum pouch with a Microwell plate (12 strips of 8 wells each) coated with SARS-CoV-2 S1RBD protein, sealed. The microwell strips can be used separately.
- 2. 10×Wash buffer-40 ml.
- 3. 5×Assay buffer-20 ml.



- 4. 100×Detection reagent: HRP-conjugated human ACE2, 0.12 ml.
- 5. 10x Positive control A (strong): An anti-S1RBD monoclonal antibody, 22 ul
- 6. 10x Positive control B (medium), An anti-S1RBD monoclonal antibod, 22 ul
- 7. Substrate solution, 12 ml, ready for use.
- 8. Stop solution, 12 ml, ready for use.
- 9. Blank control, 0.5 ml, ready for use

#### **OTHER MATERIALS REQUIRED, BUT NOT PROVIDED**

- 1. Pipettes and pipette tips.
- 2. Beakers, flasks, cylinders necessary for preparation of reagents.
- 3. Buffer and reagent reservoirs.
- 4. Paper towels or absorbent paper.
- 5. Plate reader capable of reading absorbency at 450 nm.
- 6. Distilled water or deionized water.
- 7. Statistical calculator with program to perform regression analysis.

#### STORAGE

- The kit should be stored at 2-8°C, and all reagents should be equilibrated to room temperature before use. Immediately after use remaining reagents should be returned to cold storage (2-8°C).
- Expiry of the kit and reagents is stand on labels.
- Once opened, the strips may be stored at 2-8°C for up to one month.

# SAMPLE COLLECTION AND STORAGE INSTRUCTIONS

Handle serum or plasma sample in accordance with National Committee for Clinical Laboratory Standards guidelines for preventing transmission of blood-borne infection.

- Do not use grossly hemolyzed or lipemic samples.
- Serum: Use a blood separator tube and allow sample to clot for 30 minutes, then centrifuge for 10 minutes at 1000g. When the human serum is tested, the recommended dilution factor is 100-fold.
- Plasma: Treat blood with anticoagulant such as citrate, EDTA or heparin. Centrifuge for 10 minutes at 1000g within 30 minutes for plasma collection. When the human plasma is tested, the recommended dilution factor is 100-fold.
- Samples cannot be tested immediately should be aliquoted and must be stored frozen below -20°C. Avoid repeated freeze-thaw cycle.
- The dilution factor and concentrations of other testing samples (such as inhibitors and antibodies) should be determined by individual users.

#### **PRECAUTIONS FOR USE**

- All chemicals should be considered as potentially hazardous. Avoid contact with skin and eyes. In the case of contact with skin or eyes wash with water.
- Do not use kit reagents beyond expiration date.
- Do not expose kit reagents to strong light.
- Do not pipet by mouth.
- Do not eat or smoke in area where kit reagents or samples are handled.
- Use only sufficient volume of specimen as indicated in the procedure steps. Failure to do so, may cause low sensitivity of the assay.
- Avoid contact of substrate solution with oxidizing agents and metal.
- Use disposable pipette tips and/or pipettes.
- Use clean, dedicated reagent trays for dispensing the conjugate and substrate reagent.
- Do not touch the exterior bottom of the wells; fingerprints or scratches may interfere with the reading. When reading the results, ensure that the plate bottom is dry and there are no air bubbles inside the wells.



- The enzymatic activity of the HRP-conjugate might be affected from dust and reactive chemical and substances like sodium hypochlorite, acids, alkalis etc. Do not perform the assay in the presence of these substances.
- Substrate solution must be at room temperature prior to use.

#### **PREPARATION OF REAGENTS**

Bring all reagents and materials to room temperature before use  $1.1 \times Wash$  buffer.

Prepare 1×Wash buffer by mixing the 10×Wash buffer (40 ml) with 360 ml of distilled water or deionized water. If precipitates are observed in the 10× Wash buffer bottle, warm the bottle in a 37°C water bath until the precipitates disappear. The 1×Wash buffer may be stored at 2-8°C for up to one month.

2. 1×Assay buffer.

Prepare 1x assay buffer by mixing the 5x assay buffer (20 ml) with 80 ml of distilled water or deionized water. If precipitates are observed in the 5x assay buffer bottle, warm the bottle in a  $37^{\circ}$ C water bath until the precipitates disappear. The 1x assay buffer may be stored at 2- 8°C for up to one month.

3. 1×Detection solution.

Spin down the 100×Detection solution briefly and dilute the desired amount of the antibody 1:100 with 1×Assay buffer, 100  $\mu$ L of 1×Detection antibody solution is required per well. Prepare only as much 1×Detection solution as needed. Return the 100×Detection antibody solution to 2-8°C immediately after the necessary volume is pipetted.

#### PREPARATION OF SAMPLES AND POSITIVE CONTROL

Serum or plasma sample is generally required a **100-fold dilution** in the 1X Assay buffer. A suggested dilution step is to add 2  $\mu$ L of sample to 198  $\mu$ L of 1X Assay buffer. Dilution factor can be adjusted based on the titer of the antibodies in the samples. 1X assay buffer can be used for dilution of other compounds/antibodies to desired concentrations.

Centrifuge the positive control tubes briefly before open the tube. Add 200  $\mu$ L of 1X Assay buffer and mix thoroughly.

#### **ASSAY PROCEDURE**

It is recommended that all samples be assayed in duplicate.

1. Add 100µl of samples, Blank Control and Positive Control into their respective wells, and incubate at room temperature for 1 hour. Duplicate test is recommended.

2. Discard the content and tap the plate on a clean paper towel to remove residual solution in each well. Add 300  $\mu$ l of 1×Wash buffer to each well and incubate for 1 minute. Discard the 1×Wash buffer and tap the plate on a clean paper towel to remove residual wash buffer. Repeat the wash step for a total of 3 times.

3. Add 100  $\mu$ l of 1×Detection antibody solution to each well, incubate at room temperature for 30 minutes.

4. Wash each well 3 times as described in step 2.

5. Add 100  $\mu$ l of Substrate solution to each well, incubate at room temperature for 10 minutes. Protect from light.

6. Add 100  $\mu$ l of Stop solution to each well, gently tap the plate frame for a few seconds to ensure thorough mixing.

7. Determine the optical density of each well at 450 nm immediately.



S38

S39

S40

S41

S42

S43

S44

S45

SUGG	ESTED	MICK	JPLAT	E LAYO	JUT						
BLK	BLK	S6	S6	S14	S14	S22	S22	S30	S30	S38	
PC A	PC A	<b>S</b> 7	S7	S15	S15	S23	S23	S31	S31	S39	
PC B	PC B	S8	S8	S16	S16	S24	S24	S32	S32	S40	
S1	S1	S9	S9	S17	S17	S25	S25	S33	S33	S41	
S2	S2	S10	S10	S18	S18	S26	S26	S34	S34	S42	
S3	S3	S11	S11	S19	S19	S27	S27	S35	S35	S43	
S4	S4	S12	S12	S20	S20	S28	S28	S36	S36	S44	
S5	S5	S13	S13	S21	S21	S29	S29	S37	S37	S45	

# SUGGESTED MICROPLATE LAYOUT

# **INTERPRETATION OF RESULTS**

The negative cutoff can be used for the interpretation of the inhibition efficiency.

Inhibition efficiency = 1 - 
$$\left(\frac{\text{OD value of Sample}}{\text{OD value of Negative Control}}\right) \times 100\%$$

**TYPICAL DATA** 

Sample	OD450	Inhibition efficiency (%)	Sample	OD450	Inhibition efficiency (%)
Negative Ctrl	2.98	0.00	Positive Ctrl A	1.75	41.41
Negative Ctrl	2.99	-0.17	Positive Ctrl B	1.11	62.92
	3.19	-6.88		2.78	6.57
	3.15	-5.70		2.75	7.93
	3.19	-7.15		2.74	8.06
	3.01	-1.04		2.79	6.48
	3.04	-1.98		2.38	20.15
	3.02	-1.48		1.97	33.82
	3.04	-2.11		1.70	42.92
Health control	3.15	-5.64	COVID-19	2.02	32.14
(serum)	3.19	-7.18	patients (serum)	2.69	9.97
	3.04	-2.08	(serum)	2.18	27.02
	2.88	3.29		1.13	61.98
	3.19	-6.91		1.83	38.78
	2.80	6.07		2.78	6.86
	3.03	-1.64		2.70	9.59
	3.00	-0.67		2.32	22.06
	3.14	-5.20		1.55	47.88

#### PRECISION

<u>Intra-assay:</u> Three different known levels of positive control were spiked into sample buffer as test samples. All samples were tested on the same plate to evaluate intra-assay precision of the kit. The Intra-assay precision of this kit is less than 8%.

<u>Inter-assay</u>: Three different known levels of control were spiked into sample buffer as test samples. All samples were tested in 3 separate assays to evaluate intra-assay precision of the kit. Inter-assay precision of this kit is less than 5%.



# PRECAUTIONS AND SAFETY

- 1. The ELISA assays are time and temperature sensitive. To avoid incorrect result, strictly follow the test procedure steps. 1. Do not exchange reagents from different lots or use reagents from other commercially available kits. The components of the kit are precisely matched for optimal performance of the tests.
- 2. Make sure that all reagents are within the validity indicated on the kit box and of the same lot. Never use reagents beyond their expiry date stated on labels or boxes.
- 3. CAUTION CRITICAL STEP: Allow the reagents and specimens to reach room temperature (20-25°C) before use. Shake reagent gently before use. Return at 2-8°C immediately after use.
- 4. Use only sufficient volume of specimen as indicated in the procedure steps. Failure to do so, may cause low sensitivity of the assay.
- 5. Do not touch the exterior bottom of the wells; fingerprints or scratches may interfere with the reading. When reading the results, ensure that the plate bottom is dry and there are no air bubbles inside the wells.
- 6. Never allow the microplate wells to dry after the washing step. Immediately proceed to the next step. Avoid the formation of air bubbles when adding the reagents.
- 7. Avoid long time interruptions of assay steps. Assure same working conditions for all wells.
- 8. Calibrate the pipette frequently to assure the accuracy of specimens/reagents dispensing. Use different disposal pipette tips for each specimen and reagents in order to avoid cross-contaminations.
- 9. When adding specimens, do not touch the well's bottom with the pipette tip.
- 10. When measuring with a plate reader, determine the absorbance at 450nm or at 450/600~650nm.
- 11. The enzymatic activity of the HRP-conjugate might be affected from dust and reactive chemical and substances like sodium hypochlorite, acids, alkalis etc. Do not perform the assay in the presence of these substances.
- 12. All specimens from human origin should be considered as potentially infectious. Strict adherence to GLP (Good Laboratory Practice) regulations can ensure the personal safety.
- 13. Never eat, drink, smoke, or apply cosmetics in the assay laboratory. Never pipette solutions by mouth.
- 14. Chemical should be handled and disposed of only in accordance with the current GLP (Good Laboratory Practices) and the local or national regulations.
- 15. The pipette tips, vials, strips and specimen containers should be collected and autoclaved for not less than 2 hours at 121°C or treated with 10% sodium hypochlorite for 30 minutes to decontaminate before any further steps of disposal. Solutions containing sodium hypochlorite should NEVER be autoclaved. Materials Safety Data Sheet (MSDS) available upon request.
- 16. Some reagents may cause toxicity, irritation, burns or have carcinogenic effect as raw materials. Contact with the skin and the mucosa should be avoided but not limited to the following reagents: the Stop solution, the Substrate solution, and the Wash buffer.
- 17. The Stop solution 2M  $H_2SO4$  is an acid. Use it with appropriate care. Wipe up spills immediately and wash with water if come into contact with the skin or eyes.



#### SUMMARY OF ASSAY PROCEDURE

Add 100 µl of sample or control to each well.  $\downarrow$ Incubate at room temperature for 1 hour. L Aspirate and wash each well three times.  $\downarrow$ Add 100  $\mu$ l of 1×Detection solution to each well.  $\downarrow$ Incubate at room temperature for 30 minutes.  $\downarrow$ Aspirate and wash each well three times.  $\downarrow$ Add 100 µl of Substrate solution to each well.  $\downarrow$ Incubate at room temperature for 10 minutes.  $\downarrow$ Add 100 µl of Stop solution to each well.  $\downarrow$ Measure absorbance of each well at 450 nm.  $\downarrow$ Interpretation

> Website: www.torontobioscience.com Brett Wang Covid-19 Business Development Manager brett.wang@torontobioscience.com or sales@torontobioscience.com Tel: (+1) 416 417 8573